

User Replaceable Items effective 4/14/2008

EX-90

| <u>DESCRIPTION</u> | <u>PART NUMBER</u> |
|--|--------------------|
| AC Power Cable (2-prong cable) | 1467676 |
| Lamp (V13H010L42) | 2121325 |
| Computer VGA Cable | 2110978 |
| VGA to Component Adapter | 2118180 |
| Remote Control | 1456639 |
| Projector Software CD (includes User's Guide) | CPD-23258R1 |
| Soft (black) Carrying Case with shoulder strap | 1436644 |

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.